

Type 5/6

Coverall donning

Shown accessories only exemplary



1. Check size and standards



2. Open and check for damages



3. Pull socks over trousers



4. Climb into the legs of the coverall while sitting



5. Put on rubber boots, pull coverall legs over rubber boots






12. Stretch to ensure good fit and freedom of movement



8. Put on breathing mask and goggles. Then pull over the hood
9. Close the coverall completely and remove the paper from the adhesive flap
10. Smooth out coverall and seal flap with adhesive tape







11. Put on gloves and finger loops



回線線回

Coverall doffing

7. Close coverall up to the chest



1. Release adhesive tab

2. Open zipper

3. Pull the hood backwards and turn inside out (grip at ear level)

4. Remove the sleeves and gloves by inverting, this ensures that contact is not made with the body

5. Pull the suit into the hollow of your knees and sit down. Remove the coverall and boot together

protecting people

uvex-safety.com.sg