

uvex

MADE FOR
YOUR EYES
MADE IN **UVEX**



uvex RX OMS

Order management and online configuration

The uvex RX OMS (RX Order Management System) offers customers, dealers and service partners the opportunity to place orders for uvex prescription safety glasses online with uvex and to track their status.

Spectacles are configured based on possible combinations of frames/lens properties and then checked to see whether the configuration can be produced within the certified range.

An electronic order is placed at the end of the process.

As soon as the spectacles have been sent, the status is updated in the RX OMS.



protecting people



Your benefits:

Spectacles configuration

- ✓ Easy and online
 - ✓ Based on individualised customer product ranges
 - ✓ Immediate feedback on feasibility according to EU type certification
 - ✓ Organized data management for your configuration orders incl. status tracking
- ✓ Simple registration
- ✓ Create multiple user logins for one account
- ✓ Available in several languages

What you need for uvex RX OMS:

- ✓ PC or laptop with Edge or Chrome browser
- ✓ Internet connection



Registration

Are you interested in uvex RX OMS, your online eyewear configurator? Register now free of charge at rxoms.uvex-safety.com

You can also get in touch with your uvex contact person.



Data management of orders and your product range

After logging in you can find an overview of your configuration jobs. You can:

- 1 Search for orders View
- 2 the status
- 3 View or save the order form for forwarding Create
- 4 a new order form
- 5 Export the order summary

You can view the stored customer range for your company as follows:

TESTKUNDE OH

HOME

ORDER OVERVIEW

5

EXPORT CSV

CREATE ORDER FORM

4

Order overview

Quantity 20 ▾

Order form	Customer	Department	Cost centre	Spectacle user	Optician	Status	Document (No./Pos)	Distributor	Action
1 Modified Search	Search	Search	Search	Search	Search	- ▾	Search	Search	
20241028135516B26	28.10.2024	3000008689	Assembly	Marry Jay		New			3
Testkunde OH									
20241028135512665	28.10.2024	3000008689	Building services	Harry Putter		New			
Testkunde OH									
20241028135512E9D	28.10.2024	3000008689	foundry	Jane Doe		New			
Testkunde OH									
20241028135512E2C	28.10.2024	3000008689	logistic	Max Meyer		New			
Testkunde OH									
20241028135112B23	28.10.2024	3000008689	AD	Christian Baum		New			
Testkunde OH									



Creating an order

Under "Order overview", you find a button for creating order forms. Once this has been saved, an optician or service partner can be consulted or the configuration can be started. Please note that there may be different views depending on the country.

Order overview

Order form	Modified	Customer	Department	Cost centre	Spectacle user	Optician	Status	Document (No./Pos)	Distributor	Action
28241828135516826	28.10.2024	30000008689	Assembly		Marry Jay		New			
28241828135512665	28.10.2024	30000008689	Building		Harry Putter		New			
28241828135512E9D	28.10.2024	30000008689								
28241828135512E2C	28.10.2024	30000008689								
28241828135112B23	28.10.2024	30000008689								

Order form

Customer: 3000008689 | Testkunde OH

Customer Order Number

E-mail

Phone

First name * Last name * Department

Note for optician

+ Add spectacle wearer

upload

Upload file

Update no file selected

download

☐ Consent to data processing

SAVE

Customer order number

- Corresponds to your order number
- Is saved in your account if known to uvex and is automatically pre-assigned
- Can be entered by you without pre-assignment

Your email address and telephone number are important information for the optician who may wish to contact you.

„Name“ is required field

Your additional information will be displayed during configuration.

Bulk order:
You can enter x order forms per customer order number at the same time via "Add spectacle wearer".

When using it for the first time, load the template ① and save it. You can change the name of the file, but not the headings in the columns. Enter all spectacle wearers in a file, upload ② it and carry out the update ③.

You must agree to the data protection provisions with each order. ⓘ contains further information



As our service partner, you can configure the spectacles directly online and receive immediate feedback on their feasibility.

[Home](#)
[ORDER OVERVIEW](#)
[SPECTACLE CONFIGURATION](#)

Spectacle configuration

1 Enter the order form number.

Search order form

Order form

SEARCH

CREATE NEW RECIPE

Search result

Order form	Created on	Company	Spectacle user	Action
2024102813551Z665	28.10.2024	Testkunde OH	Harry Putter	

2 Select the frame or model, and then tick the desired features. Please observe the sequence for selecting the features, as they are dependent on one another.
Material ⇒ Focal type ⇒ Anti-reflective coating ⇒ Tint ⇒ Tint in %
An option must be ticked for each feature.

Frame or Model (*)

Search by model

Lens material

Material (*)

- ☐ Plastic
- ☐ Plastic (incl. scratch-resistant coating)
- ☐ Synthetic HI 1.6 (incl. scratch-resistant coating)
- ☐ Synthetic HI 1.67 (incl. scratch-resistant coating)
- ☒ Polycarbonate (incl. scratch-resistant coating)
- ☐ PC+ (incl. scratch-resistant coating)
- ☐ Poly facet sealant
- ☐ Triplex (incl. scratch-resistant coating)
- ☐ Tempered glass

Focus type (*)

- ☒ Single Vision
- ☐ Single Vision HD
- ☐ Single Vision Relax
- ☐ Near Comfort Standard
- ☐ Near Comfort Optima
- ☐ Distance comfort Optima
- ☐ Bifokal 2B
- ☐ Bifo Comfort
- ☐ Varifocal Standard
- ☐ Varifocal Pro Work
- ☐ Varifocal Top one
- ☐ Varifocal Piccolo
- ☐ Varifocal Optima
- ☐ Varifocal Optima without inset
- ☐ Varifocal Optima HD
- ☐ Varifocal Optima HD without inset

Anti-reflective coating (*)

- ☐ without antireflection coating
- ☐ Single anti-reflection coating
- ☒ Super anti-reflective coating
- ☐ Super coating

Tint (*)

- ☒ Without tint
- ☐ Brown
- ☐ Grey
- ☐ UV 400
- ☐ UV Blue Protect

Tint in % (*)

- ☒ 0
- ☐ 12
- ☐ 15
- ☐ 25
- ☐ 65

Frames

uvex RX 5511

PSS uvex RX bc 5502 gray 56/15

Article number: 6108215

- Colour: grey
- Lens size: 56 Millimetre
- Bridge width: 15 Millimetre

CONFIGURE

protecting people



Good to know!

You can enter or have the **additional lens power values** calculated for you. You can also determine sphere, distance including the additional lens power values. RX OMS determines the near parameters for you or you can enter the sphere, distance and near and have the additional lens power values calculated for you.

Example: sphere, distance incl. additional lens power value:

Glasses type

☒ Distance glasses
 ☐ Reading glasses

☒ Entry via addition
 ☐ Entry via Short Sphere

Distance strength

Unsigned values are processed as + values.

	Sphere (Sph)	Cylinder (Zyl)	Achse (A)	Addition (ADD)
R	2,5	0,5	° 120	2
L	1		°	2

Reading strength

	Sphere (Sph)	Cylinder (Zyl)	Achse (A)
R		0,5	° 120
L			°

CALCULATION

If you choose one of our **HD focus types**, you can enter individual parameters. A suggestion is automatically generated, which you can modify for each tolerance range.

Optima HD

☒ Yes

Individual parameters

Corridor length	Reading distance	Vertex distance
mm 15,00	cm 38,00	mm 14,00
Face form angle	Pantoscopic angle	
° 5,40	° 9,00	

The **pupil distance** is always entered as PD-far. If we require the PD-near to produce the lenses, this is calculated by RX OMS. In such cases, the PD-near can also be found in the configuration overview.

Prism

You have the following options:

- Single prism (right, left, both sides): two prisms per side with base position outside, inside, top, bottom
- Resulting prism with any base position



Configuration

What do I do if certain options are greyed out or cannot be selected?

There may be two reasons for this.

- 1.) The selected frame does not support the lens property in that combination.
- 2.) The customer range for the frame and/or lens property is restricted.

The configuration is not feasible.

At the end of your configuration, you will receive a message stating whether the spectacles can be produced in combination with the frame and the optical values and whether they comply with the EU type certification. If so, the status is green. If this is not the case, the status is red and you can make an enquiry about the production of the spectacles. In such cases, we will contact you or the customer personally to discuss any changes if required.

Who can help me if I get stuck while doing the configuration?

Please contact the uvex customer service team. You can find the contact details on the last page.

Who is allowed to configure my spectacles? Any optician who is an authorised service partner of uvex may configure the spectacles.

More information

I cannot select an optician when filling out the order form.

Contact uvex and ask for the desired opticians to be added to your account. You can then assign opticians for all new order forms. The assigned opticians appear on the PDF order form.

I can find an order, but I cannot configure it.

The order form you selected has already been processed by another service partner. Please contact the uvex customer service team. You can find the contact details on the last page.

The customer's employee comes without an order form. What to do?

In such an event, it is necessary that you contact the uvex customer service team. You can find the contact details on the last page. For security reasons, it is only possible to make a configuration using the unique order form number. Please do not create a new order form, as you will be our invoiced party in this case.



Do you have any more questions?

Our team would be happy to advise you.

UVEX ARBEITSSCHUTZ GMBH
SBU Occupational Health
Würzburger Str. 152
90766 Fuerth

GERMANY

T: +49 (0) 911 9736 1998
F: +49 (0) 911 9736 1679
E: ksb@uvex.de
I: uvex-safety.de

UVEX ARBEITSSCHUTZ GMBH
SBU Occupational Health
Wuerzburger Str. 152
90766 Fuerth

INTERNATIONAL

T: +49 (0) 911 9736 1400
F: +49 (0) 911 9736 1679
E: customerservice.sbu-oh@uvex.de
I: uvex-safety.com

UVEX ARBEITSSCHUTZ (Schweiz) AG
Uferstr. 90 – Postfach
4019 Basel

SWITZERLAND

T: +41 61 638 84 40
E: ksb@uvex.ch
I: uvex-safety.ch