uvex

uvex goggles

How to fit a goggle



Fitting and Wearing Goggles



Step 1 Place the goggle on the face with one hand



Step 2 Whilst holding it in place bring the head band over and to the back of the head with the other hand (Not on the helmet)



Step 3 Adjust head band to head size



Step 4

Check the seal

- If wearing prescription glasses check that the side arms do not break the seal
- Check for gaps by running your index fingers around the seal (particularly around the nose area)

Wearing with a Respirator



Step 1 Place the goggles on first, followed by the respirator



Step 2 Make sure that the goggle sits comfortable on the respirator (nose)



Step 3 Ensure you have achieved a positive seal

Removing Goggles



Step 1 Lean slightly forward facing down and pull head band over the top of the head



Step 2 Pull goggle down from the face (take care, this is when most injuries occur)

CALL: (02) 9891 1700 for more information on uvex safety eyewear





