

uvex



2025
Prescription safety spectacles
and prescription VDU spectacles

protecting people

The uvex brand is our responsibility

We have been producing and selling high-quality products for the protection of people in sport, leisure and work for **over 90 years**. And if you want to protect people, **you have to take responsibility**.

It is precisely from this mission that our obligation derives to act in a **sustainable, social and socially-responsible** manner.

uvex Individual PPE

Organisational measures:

Durability and waste prevention

Compared to standard products (e.g. over-specs, disposable hearing protection), our custom protective products can be used for much longer. This saves valuable resources and reduces waste and CO₂ emissions over the entire period of use.

uvex hearing protection otoplastics, prescription safety spectacles and prescription VDU spectacles are supplied in reusable cases that can be used throughout their use. We are therefore making an important contribution to the prevention of packaging waste and at the same time we are extending the service life of our products.

Expertise and supply network

Decades of experience and reliable cooperation with our partners form the basis for the production of custom uvex protective products.

Our production partners are subject to regular audits and are obligated to comply with uvex social standards.

All uvex products are manufactured according to the strictest safety standards, regularly inspected, and certified by independent institutes.

uvex hazardous substances list

We do not use harmful ingredients for our individual protective products. The products are produced in accordance with the provisions of the REACH regulation and, in addition, in accordance with the requirements of the uvex banned hazardous substances list.

Durability
of uvex safety spectacles
with prescription approx.

1.5
years of use

uvex hearing
protection otoplastics

100%

nitrogen recovered from the
production process and fed
back into circulation



Packaging of uvex medicare insoles

95%

recycled cardboard

Durability of uvex
hearing protection
otoplastics approx.

5

years of use

SBU Occupational Health

Individual personal protective equipment from uvex

MADE IN UVEX



INDIVIDUAL ADJUSTMENT

Individual personal protective equipment from uvex

The health of your employees is of central importance to us through the uvex vision **protecting people.**

uvex offers individual premium solutions for protecting the eyes, ears and feet – providing maximum safety for your team.

That's because standard solutions are not enough for uvex.

Individual personal protective equipment combines a high level of innovation and individual adjustment to the wearer, making each product unique. All products from the fields of optics, otoplastics and orthopaedics are customised, ensuring that they are tailor-made to the needs of your employees.

Protective equipment that fits your employees perfectly is more likely to be worn – giving your team reliable protection.

Our custom protective products are characterised in particular by their longevity. Compared to standard products (e.g., overspecs, disposable-hearing

protection), they are used for a much longer time, saving us valuable resources and, calculated over the entire period of use, producing much less waste.



'Made in uvex'

Decades of experience and innovative technologies form the basis for products that are manufactured in accordance with the most stringent safety standards.

Whether it's eye, hearing or foot protection: Our individual personal protective equipment ensures that maximum levels of safety and comfort are provided.

Our innovations set new standards in quality and technology by combining excellent wearing comfort, attractive design and sophisticated functionality.

Our motto 'Made in uvex' guarantees a comprehensive quality system and the best possible processing technology. All materials used are free from harmful substances and are regularly inspected.

uvex places great importance on a sustainable production concept with first-class products and an in-house value creation chain, with a focus on production facilities in Germany and Europe. What's more, uvex offers maximum service with maximum flexibility.

CLAIM TO QUALITY

SBU Occupational Health

Individual personal protective equipment from uvex

Individual eye protection – uvex prescription safety spectacles

- certified prescription safety spectacles in accordance with EN 166 and Regulation (EU) 2016/425 on personal protective equipment
- wide selection of focus types and lens materials to meet all requirements
- the wide range of frames in different designs are available internationally and take into account the diverse head shapes of your employees
- qualified consultation and customisation by uvex specialists




Individual eye protection – uvex VDU spectacles

- VDU spectacles for professional use when working in front of a computer monitor and when no safety spectacles need to be worn
- wide selection of focus types and lens materials to meet all requirements
- qualified consultation and customisation by uvex specialists



Individual hearing protection – uvex high-fit

- certified otoplastic hearing protection in accordance with EN 352
- a wide selection of filters, otoplastic shapes and materials ensures that appropriate otoplastics are available for (virtually) all areas of application
- individual adjustments carried out by qualified specialists



Orthopaedic solutions for uvex safety shoes – uvex medicare

- certified orthopaedic safety footwear in accordance with EN ISO 20345:2011
- e.g. comfortable customised insoles and shoe adjustments
- wide range of usable uvex safety shoes
- uvex motion 3XL for extra-wide feet and medical conditions (e.g. diabetes)
- customisation by orthopaedics specialists



SBU Occupational Health

Individual personal protective equipment from uvex

**ONE BRAND.
ONE VISION.
ONE MISSION.**



OUR MISSION

#protecting people

The uvex brand mission. This is our objective and our responsibility. uvex protects people – when working, playing sport and pursuing leisure activities.

Decades of experience enable us to transfer expertise continuously between the sectors of industrial safety and top-level sport, and provides the foundation on which we are able to continuously develop our products.

It allows us to create innovations and solutions based on advanced technologies that reliably protect people – whether they are on a production line, on the ski slopes or on a mountain bike.

OUR FUTURE

Sustainable actions and social responsibility

If you rely on uvex, you are guaranteed sustainable actions. From environmental protection to social commitment: uvex puts corporate responsibility at the forefront of its daily business.

The focus of our commitment is to protect people:


- sustainable product concept
- avoidance of the use of hazardous beyond the requirements of the REACH regulation (the uvex banned hazardous substances list)
- uvex social standard for all manufacturing plants
- social commitment (e.g. Rainer Winter Foundation, Vision for the World)

OUR SERVICE

Time and location adapted to your needs

As an experienced specialist in occupational safety, uvex is able to offer an all-round professional service for individual personal protective equipment and meet the specific requirements of your company. Individual PPE products demand a wealth of expertise in the

consultation stage. This is why the adaptation is made by highly qualified experts – such as opticians, audiologists or orthopaedic shoe manufacturers – at a time and location to suit your needs.



Individual PPE:
For more information, visit our website.



uvexsafetygroup



uvexsafetygroup



uvexsafety



uvexsafetygroup




**Prescription
safety spectacles
and prescription
VDU spectacles**

Product system planet series › Individual PPE

uvex has developed the **protecting planet** icon, to help raise awareness of its commitment to achieving increased sustainability. Based on the brand claim, **protecting people**, our sustainable approach integrates three core interlinked pillars – **ecology, economy** and **social responsibility**, that are incorporated throughout the business to improve our sustainability performance.

This explains the comprehensive audit, measurement and evaluation management process uvex undertakes along the entire value chain to ensure its products are as sustainable as possible.

uvex RX cd 5521 planet



protecting planet

by using bio-based material //
by maximum reduction of pollutants

Material and health protection

- › the frame is mostly made of high-quality, bio-based material
- › instead of crude oil, the base is made of the renewable raw material from the castor plant
- › 38 percent of the frame is based on castor oil
- › castor cultivation does not compete with food-growing areas or endanger forested areas
- › no harmful ingredients
- › produced in accordance with the provisions of the REACH regulation and beyond, according to the specifications of the uvex banned hazardous substances list

38%

of the frame is based on castor oil

Durability approx.

1.5

years of use



Health protection

REACH

regulations are exceeded



protecting planet

by creating durable products

Durability

- › uvex prescription safety spectacles are characterised by their durability
- › the average service life is 1.5 years, which saves valuable resources and reduces CO₂ emissions



protecting planet

by using environmentally-friendly packaging //
by reducing waste

Packaging

- › uvex prescription safety spectacles are supplied with a case to extend the service life
- › the case can be reused after its useful life
- › this means we are making an important contribution to the prevention of packaging waste

Prescription safety spectacles

Individual eye protection from uvex

**MADE FOR
YOUR EYES**
MADE IN **UVEX**



uvex prescription safety spectacles are individually adapted to the wearer's vision while offering the best possible protection in the workplace.

The spectacles are certified and marked in accordance with EN 166, so they can be used in workplaces where safety spectacles are mandatory. As occupational safety spectacles, they not only protect the eyes (from UV radiation, flying particles, dust etc.), but are also a visual aid because the lenses have a dioptric effect.

uvex offers a wide range of high-quality lens materials, focus types and frames. This makes it easier to switch between personal spectacles and employer-provided safety spectacles, which increases wearer acceptance.

The comprehensive uvex quality system guarantees the best design from an optical and processing technology perspective. All materials used (lenses, frames, cases etc.) are free from harmful substances and are regularly inspected.

The collection

uvex offers a variety of frames for prescription safety spectacles.

uvex RX bc plastic



- bc: basic collection
- in different shapes, sizes and colours

uvex RX bc metal



- bc: basic collection
- in different shapes, sizes and colours

uvex RX ti



- ti: titan
- made of high-quality titanium
- extremely stable
- lightweight
- allergy-neutral

uvex RX cb



- cb: custom bridge
- Suitable for people with:
- a flat nose bridge
 - high cheekbones
 - wide temples

uvex RX cd



- cd: comfort and design
- safety spectacles in a sporty design

uvex RX sp



- sp: sporty
- safety spectacles in a wrap-around design for anatomic sport lenses

uvex RX cd flip-up



- cd: comfort and design
- for workplaces with special requirements

uvex RX cf



- cf: close fit
- safety spectacles with all-round protection and tailored to your individual prescription
- recommended for handling chemicals and/or working in dusty environments

Prescription safety spectacles

Individual eye protection from uvex

uvex as a partner for individual protective equipment

Our eyesight needs special protection – and many activities in our working lives leave them vulnerable to serious risks. uvex does not compromise on eye protection and offers reliable protection with individually adapted safety spectacles.

Decades of experience and innovative technologies form the basis for uvex products, which are manufactured in accordance with the most stringent safety standards. In addition to safety, uvex also guarantees maximum comfort and quality. Protective equipment that fits properly not only offers reliable protection, but is more likely to be worn by the employee.

Our service – your benefits

uvex offers maximum service with maximum flexibility. Our specialists are happy to advise you with regard to professional and flexible solutions, tailored to the individual requirements of your company.

Our wide uvex collection enables us to find prescription safety spectacles for each of your employees.



uvex experts:

- on-site service from qualified opticians and master opticians
- qualified advisers in uvex customer service
- comprehensive uvex optical service partner network in Germany, Austria and Switzerland, as well as in other European countries



uvex flexibility:

- product consultation and adaptations on request.
- appointments are also possible during the early, late or night shift
- uvex online appointment tool optimises planning




uvex expertise:

- decades of experience in optics and continuous development of products
- training courses/practical seminars for your employees (e.g. company doctors, occupational safety specialists)
- 'Made in uvex' quality: First-class products with an in-house value creation chain and a focus on production facilities in Germany/Europe



digital service tools:

- uvex RX lens consulting for the optimal product selection for your requirements
- uvex centRX, the web-based centring tool for determining the necessary centring parameters to order your individual safety spectacles



www.uvex-safety.com/en/individual-ppe/digital-servicetools/

The easy steps to your prescription safety spectacles

1 Scheduled appointment and consultation

Make an appointment by phone or email and get advice from uvex experts on prescription safety spectacles.

+49 911 97361400

customerservice.sbu-oh@uvex.de

2 Workplace analysis and product search

Our uvex specialists will be happy to present our uvex collection in person at your company and will conduct a workplace analysis with you to find the best products for you and your employees.

3 Finished prescription safety spectacles

After consulting and selecting your personal product, either on-site or at one of the uvex optical service partners, your prescription safety spectacles will be ready for you in a timely manner.


Please contact us for further, non-binding information.

Prescription safety spectacles

uvex international service expertise

UVEX SERVICE NETWORK

Service partners & opticians



uvex strives to provide you and your employees with uvex prescription safety spectacles, no matter where your company is located. That's why we offer an international uvex network of production facilities and service partners in many countries. This network is continuously being expanded.



Perfect fit around the globe

Many frames can be anatomically adapted to different head shapes to ensure a perfect fit, e.g. for



high cheek bones



flat nose bridge



wide temples

Our uvex RX cb and uvex RX cd collections meet the standard requirements for the field of view and coverage for both the European test head and the Asian test head.




Further information can be obtained via:

- +49 911 9736-1400
- customerservice.sbu-oh@uvex.de

Digital service tools

uvex centRX – uvex RX lens advice


**MADE FOR
YOUR EYES**
MADE IN UVEX



www.uvex-safety.com/en/individual-ppe/digital-servicetools/

Maximum service with maximum flexibility

With our uvex RX lens consulting and uvex centRX digital service tools, we offer useful service tools in the fields of prescription safety spectacles and prescription VDU spectacles, which provide you with valuable information at a glance to facilitate your daily work or the ordering process.



www.uvex-safety.com/en/uvex-rx-lens-consulting/

uvex RX lens consulting


Optimal selection of products – conveniently online

What are the advantages of the different lens types and coatings for innovative uvex prescription safety spectacles? Find the optimum product to meet requirements quickly and easily using the practical uvex RX app.



uvex centRX – customisation – simple, fast, digital

The uvex centRX [pronounced 'sentricks'] photo-centring tool is a web-based, easy-to-use solution for quickly and reliably determining the necessary centring parameters for ordering uvex safety and VDU prescription spectacles. It offers customers, retailers and service partners the opportunity to determine the necessary parameters via a photo and to order glasses digitally using the simple menu navigation. The centring requirements of individual focus groups are stored in the application, so that the possibility of calculation errors in determining the specific height is eliminated.



centrx.uvex-safety.com

Your benefits at a glance:

Determine independent, custom centring parameters for ordering lenses


- ✓ Very simple and digital
- ✓ web-based, no installation required
- ✓ No registration required
- ✓ No data storage
- ✓ Available in German and English

What you need for uvex centRX:

- ✓ PC, laptop or notebook with Internet browser Edge, Chrome or Firefox
- ✓ Ability to shoot photos in .jpg/.jpeg/.png formats
- ✓ An Internet Connection

🌐 Start straightaway without registering

Are you interested in uvex centRX? Feel free to add our web address as a favourite in your browser. You can start the application online immediately.



centrx.uvex-safety.com

uvex

Prescription safety spectacles

uvex RX bc plastic frames



Basic collection

uvex RX bc plastic

classic
timeless
virtually unrestricted prescription lenses



6109252



6109253

uvex RX bc 5523

- round plastic frame with metal arms
- transparent side shields
- good fit with anatomically shaped nose bridge and easily adjustable earpieces

uvex RX bc 5523		
Art. no.	6109252	6109253
Ref. no.	5523 1525 49/20	5523 7415 49/20
Lens diameter	49 mm	49 mm
Bridge width	20 mm	20 mm
Colour	grey, translucent	green, grey
Extras	metal arms	metal arms
Marking on frame	W 166 FT CE	W 166 FT CE

Prescription safety spectacles

uvex RX bc plastic frames



6109219
6109203



6109204

uvex RX bc 5503

- plastic frames with classic lens shape
- transparent side shields with integrated brow guard
- good fit with anatomically shaped nose bridge

uvex RX bc 5503			
Art. no.	6109219	6109203	6109204
Ref. no.	5503 1300 50/17	5503 1300 54/17	5503 7415 54/17
Lens diameter	50 mm	54 mm	54 mm
Bridge width	17 mm	17 mm	17 mm
Colour	anthracite	anthracite	green, grey
Extras			metal arms with spring hinges
Marking on frame	W 166 FT CE	W 166 FT CE	W 166 FT CE



6108215



6109210

uvex RX bc 5502

- close-fitting plastic frames
- side shields and integrated brow guard frame design
- specially shaped frames provide protection against particles from below
- good fit with anatomically shaped nose bridge
- individually adjustable side arms with four different lengths and adjustable soft-form comfort ear pieces

uvex RX bc 5502	
Art. no.	6108215
Ref. no.	5502 1725 56/15
Lens diameter	56 mm
Bridge width	15 mm
Colour	grey
Marking on frame	W 166 F CE

uvex RX bc 5506

- comfortable plastic frame
- side shields and integrated brow guard frame design
- good fit with anatomically shaped nose bridge

uvex RX bc 5506	
Art. no.	6109210
Ref. no.	5506 1725 56/18
Lens diameter	56 mm
Bridge width	18 mm
Colour	light grey, translucent
Marking on frame	W 166 F CE

uvex

Prescription safety spectacles

uvex RX bc metal frames

Basic collection
uvex RX bc metal

classic
timeless
virtually unrestricted prescription lenses



6109114

uvex RX bc 5109

- modern, rounded metal frame
- transparent side shields
- anatomically adjustable nose pads and ear-pieces ensure an exceptional fit

uvex RX bc 5109	
Art. no.	6109114
Ref. no.	5109 6100 50/19
Lens diameter	50 mm
Bridge width	19 mm
Colour	gold
Marking on frame	W 166 FT CE



6109115

uvex RX bc 5110

- classic, square metal frame
- transparent side shields
- anatomically adjustable nose pads and ear-pieces ensure an exceptional fit

uvex RX bc 5110	
Art. no.	6109115
Ref. no.	5110 1300 55/17
Lens diameter	55 mm
Bridge width	17 mm
Colour	anthracite
Marking on frame	W 166 FT CE



6109116

uvex RX bc 5111

- large metal frame in a retro design featuring a double bridge
- transparent side shields
- anatomically adjustable nose pads and ear-pieces ensure an exceptional fit

uvex RX bc 5111	
Art. no.	6109116
Ref. no.	5111 1800 57/19
Lens diameter	57 mm
Bridge width	19 mm
Colour	silver
Marking on frame	W 166 FT CE

Prescription safety spectacles

uvex RX bc metal frames



6109100
6109101

uvex RX bc 5102

- fashionable, aviator-style metal frame
- transparent side shields
- anatomically adjustable nose bridge and ear-pieces ensure an exceptional fit

uvex RX bc 5102		
Art. no.	6109100	6109101
Ref. no.	5102 1400 51/20	5102 1400 53/20
Lens diameter	51 mm	53 mm
Bridge width	20 mm	20 mm
Colour	gunmetal, matt	gunmetal, matt
Marking on frame	W 166 FT CE	W 166 FT CE



6109104
6109105

uvex RX bc 5103

- classic design metal frame with double bridge
- transparent side shields
- anatomically adjustable nose bridge and ear-pieces ensure an exceptional fit

uvex RX bc 5103		
Art. no.	6109104	6109105
Ref. no.	5103 1400 53/17	5103 1400 55/17
Lens diameter	53 mm	55 mm
Bridge width	17 mm	17 mm
Colour	gunmetal, matt	gunmetal, matt
Marking on frame	W 166 FT CE	W 166 FT CE



6109108
6109109

uvex RX bc 5106

- classic design metal frame
- transparent side shields
- anatomically adjustable nose bridge and ear-pieces ensure an exceptional fit

uvex RX bc 5106		
Art. no.	6109108	6109109
Ref. no.	5106 1400 50/20	5106 1400 52/20
Lens diameter	50 mm	52 mm
Bridge width	20 mm	20 mm
Colour	gunmetal, matt	gunmetal, matt
Marking on frame	W 166 FT CE	W 166 FT CE



6109112
6109113

uvex RX bc 5108

- slim, expressive metal frame
- transparent side shields
- anatomically adjustable nose bridge and ear-pieces ensure an exceptional fit

uvex RX bc 5108		
Art. no.	6109112	6109113
Ref. no.	5108 3400 54/19	5108 3400 56/19
Lens diameter	54 mm	56 mm
Bridge width	19 mm	19 mm
Colour	steel blue	steel blue
Marking on frame	W 166 FT CE	W 166 FT CE



6109103

uvex RX bc 5101

- classic design metal frame with double bridge
- side shields made of wire mesh for good air circulation
- anatomically adjustable nose pads
- arms with sprung hinges and easily adjustable earpieces

uvex RX bc 5101		
Art. no.		6109103
Ref. no.		5101 1018 56/17
Lens diameter		56 mm
Bridge width		17 mm
Colour		black, silver
Marking on frame		W 166 FT CE

uvex

Prescription safety spectacles

uvex RX ti

Titanium collection

uvex RX ti

lightweight
allergy-neutral
corrosion-resistant



6109404

uvex RX ti 5904

- thin, lightweight titanium frame
- transparent side shields
- lightweight, allergy-neutral and corrosion-resistant
- anatomically adjustable nose pads and ear-pieces ensure an exceptional fit

uvex RX ti 5904

Art. no.	6109404
Ref. no.	5904 1900 52/19
Lens	52 mm
Bridge width	19 mm
Colour	silver, matt
Marking on frame	W 166 FT CE



6109405

uvex RX ti 5905

- large titanium frame in a retro design featuring a double bridge
- transparent side shields
- lightweight, allergy-neutral and corrosion-resistant
- anatomically adjustable nose pads and ear-pieces ensure an exceptional fit

uvex RX ti 5905

Art. no.	6109405
Ref. no.	5905 1900 57/19
Lens	57 mm
Bridge width	19 mm
Colour	silver, matt
Marking on frame	W 166 FT CE

Prescription safety spectacles

uvex RX cb

custom bridge
uvex RX cb

perfect fit for
high cheekbones
wide temples
flat nose bridge



6109232

uvex RX cb 5580

- wide fitting plastic frame for the best fit
- frame design with side shields and integrated brow guard
- easily adjustable, soft-form ear pieces for extra comfort
- ideal for individuals with a flat nose bridge, high cheekbones and/or wide temples.
- tested for use with Asian headform 2M, DIS ISO 18526-4:2018

uvex RX cb 5580	
Art. no.	6109232
Ref. no.	5580 3015 57/14
Lens	57 mm
Bridge width	14 mm
Colour	dark blue, grey
Marking on frame	W 166 F CE



6109233











uvex RX cb 5581

- plastic frame with extra wide temple width
- frame design with side shields and integrated brow guard
- easily adjustable, soft-form ear pieces for extra comfort
- ideal for individuals with a flat nose bridge, high cheekbones and/or wide temples.
- tested for use with Asian headform 2M, DIS ISO 18526-4:2018

uvex RX cb 5581	
Art. no.	6109233
Ref. no.	5581 1542 58/14
Lens	58 mm
Bridge width	14 mm
Colour	grey, dark red
Marking on frame	W 166 F CE

Prescription safety spectacles

Lens options uvex RX bc for plastic and metal frames · uvex RX ti · uvex RX cb

Focus type		Lens type	Parameter for centering of the lenses
Description			Specific height Box measure
Single vision			
<ul style="list-style-type: none"> - Correction of visual defect in far, in-between or near distance 		Single vision, Single vision HD	Single vision HD ≥ centre of lens Main line of sight
Certified prescription range			
Comfort lenses			
Nahcomfort - Version with expanded near vision - Ideal for workplace environments of 30 cm to approx. 2 m Distanzcomfort - Calculation of the individual correction for defined distances (1 m, 2 m or 4 m) Single vision Relax - To accommodate the prescription for the lower part of the lens, the prescription is increased by +0.5 of a diopter	  	Nahcomfort Standard, Nahcomfort Optima Versions see page 40 Distanzcomfort Optima Single vision Relax	min. 17 mm Main line of sight min. 17 mm Zero line of sight min. 15 mm Zero line of sight
Certified prescription range			
Bifocal			
<ul style="list-style-type: none"> - Correction of visual defect in far and reading distance - Visible segment for near distance - Steplike change from far distance to near distance at the edge of segment - Bifocal: Instantly well-tolerated, visible edge of segment supports orientation 	Bifocal 	Width of segment: 28 mm, curved	
Certified prescription range			
Varifocals			
<ul style="list-style-type: none"> - Correction of visual defect in far, in-between and near distance - Gliding change from far distance to near distance (progressive canal) - The non-visible gliding zone corrects in-between distances 	    Varifocal Optima, Optima HD 	Varifocal Standard - Standard area for far distance and near distance - Long, narrow canal of progression Varifocal Pro Work - Large area for far distance - Wide canal of progression - Optimized area for reading distance Varifocal Piccolo - Suitable for flat frames - Large area for far distance and near distance - Shortened canal of progression Varifocal Top One - Very comfortable, large long-distance and close-up field of vision - Wide canal of progression for added convenience - Minimal blur in peripheral vision Varifocal Optima, Optima HD - Individual adjusted multifocal lens of latest generation - Wide field of view for any distance - Improved design - Almost no blurred zones in periphery area >> Version HD see page 40	min. 23 mm Zero line of sight min. 20 mm Zero line of sight min. 17 mm Zero line of sight min. 19 mm Zero line of sight Optima min. 17 mm Optima HD min. 16 mm (depending on the corridor length) Zero line of sight
Certified prescription range			

- ▶ The overview shows the maximum prescription range which is approved and certified. Depending on the size of the frame and the lens material, further restrictions may apply.
- ▶ Please take into account the specifications relating to the line of sight when determining the vision point.

Material							Extras, optional				
CR 39	HI 1.6	Plastic HI 1.67	PC	Trivex	Silicate Hard glass	Normal AR	Super AR	UV blue protect	Tint	Variomatic brown	
■	■	■	■	■	HD not available	■	■	■	■	■	
	incl. hard coating only available with SAR recommended from +/- 4.0 dpt.	incl. hard coating only available with SAR recommended from +/- 6.0 dpt.	incl. hard coating	incl. hard coating	only available without AR or with SAR	only single vision	■	only HI 1.67 or PC		only Polycarbonate or Trivex	
+10.0 to -10.0 dpt. at maximum value cyl. ± 8.0 dpt.	+12.0 to -13.0 dpt. at maximum value cyl. ± 8.0 dpt.	+13.0 to -14.5 dpt. at maximum value cyl. ± 8.0 dpt.	+9.5 to -12.0 dpt. at maximum value cyl. ± 8.0 dpt.	+8.0 to -11.0 dpt. at maximum value cyl. ± 7.0 dpt.	+7.0 to -6.0 dpt. at maximum value cyl. ± 4.0 dpt.					+7.5 to -8.5 dpt. at maximum value cyl. ± 6.0 dpt.	
Standard/ Optima	only Optima	only Optima	Standard/ Optima	only Optima	—	■	■	only HI 1.67 or PC	—	—	
■	■	■	■	■	—	■	■	only HI 1.67 or PC	—	—	
■	■	■	■	■	—	■	■	only HI 1.67 or PC	—	—	
+9.0 to -7.5 dpt. at maximum value cyl. ± 6.0 dpt.	+8.0 to -8.0 dpt. at maximum value cyl. ± 6.0 dpt.	+9.0 to -10.0 dpt. at maximum value cyl. ± 6.0 dpt.	+9.0 to -6.0 dpt. at maximum value cyl. ± 6.0 dpt.	+7.0 to -6.0 dpt. at maximum value cyl. ± 4.0 dpt.							
■	Bifocal only	—	■	—	■	■	■	—	■	—	
+7.0 to -8.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0	+8.5 to -10.5 dpt. at maximum value cyl. ± 8.0 dpt. Add. +3.0		+10.0 to -10.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0		+6.0 to -6.0 dpt. at maximum value cyl. ± 4.0 dpt. Add. +3.0						
■	■	■	■	—	■	■	■	—	■	only Polycarbonate	
■	■	■	■	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex	
■	■	■	■	—	—	■	■	—	■	only Polycarbonate	
■	■	■	■	—	■	■	■	only HI 1.67 or PC	■	only Polycarbonate	
■	only Optima and Optima HD	only Optima and Optima HD	■	only Optima and Optima HD	—	only Optima	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex	
+6.0 to -10.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0	+9.5 to -12.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0	+10.0 to -12.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0	+9.5 to -10.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0	+6.0 to -13.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0	+6.0 to -6.0 dpt. at maximum value cyl. ± 4.0 dpt. Add. +3.0					+7.5 to -10.0 dpt. at maximum value cyl. ± 6.0 dpt. Add. +3.0	

uvex

Prescription safety spectacles

uvex RX cd

comfort and design
uvex RX cd

modern
sporty
protective functions integrated into
frame design



6109257*



6109249*



Reflective uvex logo


uvex RX cd 5521 planet · uvex RX cd 5521

- the uvex RX cd 5521 planet frame is primarily made of high-quality, bio-based material; instead of crude oil, this material is based on the renewable raw material of the castor plant; the total percentage of the castor oil base is 38%
- stylish plastic frame with reflective uvex logo
- transparent lens frame for an unrestricted field of view
- good fit thanks to anatomically shaped nose bridge
- sporty arms made from a combination of soft and hard components to ensure increased comfort and non-slip fit

	uvex RX cd 5521 planet	uvex RX cd 5521
Art. no.	6109257*	6109249*
Ref. no.	5521 1369 54/22	5521 1813 54/22
Lens diameter	54 mm	54 mm
Bridge width	22 mm	22 mm
Colour	anthracite, jade	silver, anthracite
Marking on frame	W 166 F CE	W 166 F CE

Prescription safety spectacles

uvex RX cd 5521 planet



The renewable raw material from the castor plant forms the base




High-quality, bio-based polyamides conserve resources

38%

is the total percentage of the castor oil base for the frame

SUSTAINABLE MODERN SAFE



Excellent wearer comfort
› easy-to-adjust, soft ear-pieces

Always visible
› reflective uvex logo

Unrestricted field of vision
› transparent lens frame

6109257

Sporty design
› increased wearer acceptance

protecting planet
by using bio-based material // by maximum reduction of pollutants

- › the frame is mostly made of high-quality, bio-based material
- › instead of crude oil, the base is the renewable raw material from the castor plant
- › 38% of the frame is based on castor oil
- › castor cultivation does not compete with food-growing areas or endanger forested areas
- › no harmful ingredients
- › produced in accordance with the provisions of the REACH regulation and beyond, according to the specifications of the uvex banned hazardous substances list

protecting planet
by creating durable products

- › uvex prescription safety spectacles are characterised by their durability
- › the average service life is 1.5 years, which saves valuable resources and reduces CO₂ emissions

protecting planet
by using environmentally-friendly packaging // by reducing waste

- › uvex prescription safety spectacles are supplied with a case to extend the service life
- › the case can be reused after its useful life
- › this means we are making an important contribution to the prevention of packaging waste

► Please note the lens options for uvex RX cd on pages 28/29.

Prescription safety spectacles

uvex RX cd



6109254



6109255

uvex RX cd 5524 planet

- modern, close-fitting plastic frame
- the frame is primarily made of high-quality, bio-based material. Instead of crude oil, this material is based on the renewable raw material of the castor plant
- the total percentage of the castor oil base for the frame is 38%
- translucent frame colour for an unobstructed field of vision
- frame design with integrated side shields and upper eye coverage
- soft, adjustable nose bridge
- easily adjustable soft-form comfort ear-pieces



protecting planet

by using bio-based material

uvex RX cd 5524 planet

Art. no.	6109254*	6109255*
Ref. no.	5524 2513 53/16	5524 2513 57/16
Lens diameter	53 mm	57 mm
Bridge width	16 mm	16 mm
Colour	translucent, anthracite	translucent, anthracite
Marking on frame	W 166 F CE	W 166 F CE



6109225*



6109226*

uvex RX cd 5514

- close-fitting plastic frame
- transparent side shields and integrated brow guard frame design
- soft, adjustable nose bridge
- easily adjustable soft-form comfort ear pieces

uvex RX cd 5514

Art. no.	6109225*	6109226*
Ref. no.	5514 1033 53/18	5514 1045 55/18
Lens diameter	53 mm	55 mm
Bridge width	18 mm	18 mm
Colour	black, blue	black, red
Marking on frame	W 166 F CE	W 166 F CE

► Please note the glazing options for uvex RX cd on pages 28/29.

Prescription safety spectacles

uvex RX cd 5526



uvex RX cd 5526

- plastic frame with sporty design
- the frame is primarily made of high-quality, bio-based material; instead of crude oil, this material is based on the renewable raw material of the castor plant; the total percentage of the castor oil base for the frame is 38%
- translucent lens frame for an unobstructed field of vision
- good fit thanks to anatomically shaped nose bridge
- easily adjustable, soft ear-pieces with metal core



uvex RX cd 5526		
Art. no.	6109260	6109261
Ref. no.	5526 1015 54/18	5526 1341 54/18
Lens diameter	54 mm	54 mm
Bridge width	18 mm	18 mm
Colour	black, grey	anthracite, red
Marking on frame	W 166 F CE	W 166 F CE

► Please note the glazing options for uvex RX cd on pages 28/29.


uvex

Prescription safety spectacles

uvex RX cd 5522

uvex RX cd 5522 tight-fit-kit

FLEXIBLE / ROBUST / SAFE



uvex RX cd 5522


- modern plastic frame in a robust design
- translucent frame colour for an unobstructed field of vision
- air vents at the top and side
- soft, adjustable nose bridge
- sporty arms made from a combination of soft and hard components to ensure increased comfort and non-slip fit
- soft, adjustable ear-pieces with metal core



Accessories for extra protection against liquids

uvex RX cd 5522 tight-fit-kit

- set consisting of seal and headband
- seal made of hard and soft components provides a tight fit
- protection against liquids (droplets) – marking 3, in accordance with EN 166
- headband for a more secure fit, can be fitted straight onto the side arms



Seal
 › simply clip into the upper and side air vents of the frame to close them and fix the seal



	uvex RX cd 5522	uvex RX cd 5522 tight-fit-kit
Art. no.	6109250	6118012
Ref. no.	5522 2533 58/15	
Lens diameter	58 mm	
Bridge width	15 mm	
Colour	translucent-grey, blue	black, anthracite
Marking on frame	Frame: W 166 F CE	Face seal: W 166 3F CE
Compatible with	6118012	6109250
Order unit		PC

uvex RX cd 5522 (6109250) with uvex RX cd 5522 tight-fit-kit (6118012)

► Please note the glazing options for uvex RX cd on pages 28/29.

Prescription safety spectacles

uvex RX cd



6109230*



6109234*

uvex RX cd 5518

- sporty frame design: attractive and durable
- metal-free
- comfortable soft arms (uvex duo component technology), non-slip fit without pressure points
- good fit thanks to anatomically shaped nose bridge

uvex RX cd 5518		
Art. no.	6109230*	6109234*
Ref. no.	5518 1341 54/22	5518 1333 54/22
Lens diameter	54 mm	54 mm
Bridge width	22 mm	22 mm
Colour	anthracite, red	anthracite, blue
Marking on frame	W 166 F CE	W 166 F CE

► Please note the glazing options for uvex RX cd on pages 28/29.



6109208
6109209



6118000
6118001



uvex RX cd 5505 with uvex RX cd seal

uvex RX cd 5505

- close-fitting plastic frames
- integrated side shields and brow guard for an exceptionally close fit
- specially shaped frames provide protection against particles from below
- good fit with anatomically shaped nose bridge
- individually adjustable side arm length and angle for a customised fit and adjustable soft-form comfort ear pieces

uvex RX cd 5505		
Art. no.	6109208	6109209
Ref. no.	5505 2900 55/19	5505 2900 57/19
Lens diameter	55 mm	57 mm
Bridge width	19 mm	19 mm
Colour	transparent	transparent
Marking on frame	W 166 F CE	W 166 F CE

uvex RX cd 5505 seal











- foam seal frame for uvex RX cd 5505 for use when working with dust, chips or fluids
- complies with EN 166 "Protection against liquid droplets and splashes" (category "3")

uvex RX cd 5505 seal		
Art. no.	6118000	6118001
Ref. no.	5505 seal 55/19	5505 seal 57/19
Lens diameter	55 mm	57 mm
Bridge width	19 mm	19 mm
Colour	black	black
Order unit	PC	PC
seal marking	W 166 3 F CE	W 166 3 F CE

► Please note the glazing options for uvex RX cd on pages 28/29.

Prescription safety spectacles

Lens options for uvex RX cd · uvex RX cf 5500 - uvex RX cf 5501

		Lens type	Parameter for centering of the lenses
Description			Specific height Box measure
Single vision			
		Single vision, Single vision HD	Single vision HD min. centre of lens Main line of sight
Prescription range			
Comfort lenses			
			
Nahcomfort Standard	Nahcomfort Optima	Distanzcomfort Optima	Single vision Relax
		Nahcomfort Standard, Nahcomfort Optima (Versions see page 40)	min. 17 mm Main line of sight
		Distanzcomfort Optima	min. 17 mm Zero line of sight
		Single vision Relax	min. 15 mm Zero line of sight
Prescription range			
Bifocal			
			Width of segment: 28 mm, curved
			Bifocal
Prescription range			
Varifocals			
			
Varifocal Standard	Varifocal Pro Work	Varifocal Piccolo	Varifocal Top One
			Varifocal Optima
			Varifocal Optima HD
		Varifocal Standard	min. 23 mm Zero line of sight
		Varifocal Pro Work	min. 20 mm Zero line of sight
		Varifocal Piccolo	min. 17 mm Zero line of sight
		Varifocal Top One	min. 19 mm Zero line of sight
		Varifocal Optima	min. 17 mm Zero line of sight
		Varifocal Optima HD	min. 16 mm (depending on the corridor length) Zero line of sight
Prescription range			

► In order to ensure optimum vision, uvex compensate the values in accordance to the frame wrap angle (FWA).
 The overview below provides information on the lens options for uvex RX cd frames.
 Please also ensure the frame fits correctly.

► Please take into account the specifications relating to the line of sight when determining the vision point.

	Material					Extras, optional				
	CR 39	HI 1.6	Plastic HI 1.67	PC	Trivex	Normal AR	Super AR	UV blue protect	Tinting	Variomatic brown
	■	■	■	■	■	■	■	■	■	■
		incl. hard coating only available with SAR	incl. hard coating only available with SAR	incl. hard coating	incl. hard coating	only single vision		only HI 1.67 or PC		only Polycarbonate or Trivex
	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.					+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.
	Standard/Optima	only Optima	only Optima	Standard/Optima	only Optima	■	■	only Optima, HI 1.67 or PC	—	—
	■	■	■	■	■	■	■	only HI 1.67 or PC	—	—
	■	■	■	■	■	■	■	only HI 1.67 or PC	—	only Polycarbonate
	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.					
	■	Bifocal only	—	■	—	■	■	—	■	—
	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.		+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.						
	■	■	■	■	—	■	■	—	■	only Polycarbonate
	■	■	■	■	■	■	■	only, HI 1.67 or PC	■	only Polycarbonate or Trivex
	■	■	■	■	—	■	■	—	■	only Polycarbonate
	■	■	■	■	—	■	■	only, HI 1.67 or PC	■	only Polycarbonate
	■	■	■	■	■	■	■	only, HI 1.67 or PC	■	only Polycarbonate or Trivex
	■	■	■	■	■	only Optima	■	only, HI 1.67 or PC	■	only Polycarbonate or Trivex
	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.	+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.					+6.0 to -6.0 dpt. at maximum value cyl. ±4.0 dpt.

uvex

Prescription safety spectacles

uvex RX sp



sporty
uvex RX sp

dynamic
wrap-around design
protective functions integrated
in frame design



uvex anatomic sport lens

- we only use lenses with a base curve that is identical to the curvature of the frame.
- prescription values are recalculated based on the angle of the lenses and taken into account during the glazing process.



uvex RX sp 5513 planet · uvex RX sp 5513

- The uvex RX sp planet frame is primarily made of high-quality, bio-based material. Instead of crude oil, this material is based on the renewable raw material of the castor plant. The total percentage of the castor oil base is 38%.
- sporty, plastic “wraparound” design with curved lenses and anatomic sport glazing
- side shield and integrated brow guard frame design
- good fit with anatomically shaped soft nose bridge
- sporty arms with a combination of soft and hard components ensure increased comfort and non-slip fit

	uvex RX sp 5513 planet	uvex RX sp 5513
Art. no.	6109256	6109222
Ref. no.	5513 1369 62/16	5513 1577 62/16
Lens diameter	62 mm	62 mm
Bridge width	16 mm	16 mm
Colour	anthracite, jade	grey, light green
Marking on frame	W 166 F CE	W 166 F CE

► Please note the glazing options for uvex RX sp on pages 34/35.

Prescription safety spectacles

uvex RX sp



6109216



6109217

uvex RX sp 5510

- sporty, plastic “wraparound” design with curved lenses and anatomic sport glazing
- side shield and integrated brow guard frame design
- good fit with anatomically shaped soft nose bridge
- sporty arms with a combination of soft and hard components ensure increased comfort and non-slip fit

uvex RX sp 5510		
Art. no.	6109216	6109217
Ref. no.	5510 1217 62/17	5510 1248 62/17
Lens diameter	62 mm	62 mm
Bridge width	17 mm	17 mm
Colour	matt black, light grey	matt black, orange
Marking on frame	W 166 F CE	W 166 F CE

► Please note the glazing options for uvex RX sp on pages 34/35.



6109220



6109221

uvex RX sp 5512

- sporty, plastic “wraparound” design with curved lenses and anatomic sport glazing
- uvex tight-fit-kit consisting of headband and foam material available
- side shield and integrated brow guard frame design
- the arms can be replaced with a headband for a more secure fit when working in extreme conditions
- the foam material guarantees a close and firm fit.
- very good fit with anatomically adjustable, soft nose bridge
- sporty side arms with a combination of soft and hard components ensure increased comfort and non-slip fit

Applications in combination with the tight-fit-kit:

- working in extreme situations, such as overhead or in confined spaces
- working with fluids (drops) or chips and dust
- complies with EN 166 “Protection against liquid droplets and splashes” (category “3”)

uvex RX sp 5512		
Art. no.	6109220	6109221
Ref. no.	5512 5573 65/16	5512 1348 65/16
Lens diameter	65 mm	65 mm
Bridge width	16 mm	16 mm
Colour	brown, olive	anthracite, orange
Marking on frame	W 166 F CE	W 166 F CE

uvex RX sp 5512 tight-fit-kit		
Art. no.	6118004	6118005
Colour	brown, olive	anthracite, orange
Order unit	PC	PC
tight-fit-kit marking	W 166 3 F CE	W 166 3 F CE

► Please note the glazing options for uvex RX sp on pages 34/35.



6118004



6109220 assembled with uvex RX sp 5512 tight-fit-kit 6118004



6118005



6109221 assembled with uvex RX sp 5512 tight-fit-kit 6118005

uvex

uvex RX cf 9501

goggle with direct prescription lenses

close fit uvex RX cf

- close-fitting
- all-round protection
- direct glazing
- solutions using RX insert



Recommended use/glazing

Lens material: PC*

- Workplaces with a high risk of mechanical hazards
- such as metal-cutting shaping, turning, grinding and milling
- Mechanical strength "B", 120 m/s

Lens material: Trivex

- Workplaces with a high risk of chemical hazards
- such as laboratories and those handling small quantities of chemicals
- Mechanical strength "F", 45 m/s

uvex RX cf 9501

- goggles with custom prescription
- direct prescription lenses provide exceptional optical quality without aberrations or loss of light
- comfortable TPE frame, stays comfy even when worn for longer periods
- high level of mechanical strength ("B", 120 m/s)
- meets the requirements for additional markings 3 (liquids, droplets) and 4 (coarse dust)

uvex RX cf 9501	
Art. no.	6109501
Ref. no.	9501 1333 61/14
Lens diameter	61 mm
Bridge width	14 mm
Colour	anthracite, blue
Marking on frame	W 166 34 B CE

► Please note the glazing options for uvex RX cf 9501 on pages 34/35.



Direct prescription lenses

Prescription safety lenses are inserted directly into the goggle frame according to the individual prescription strength.



Sophisticated ventilation

Direct and indirect air vents ensure optimum protection and excellent ventilation for "eye zone" comfort.



Flexible headband clip

The flexible headband clip allows the goggle to adjust to different facial shapes for a customised fit. The comfortable fabric headband keeps the uvex RX cf 9501 securely in place.

For further information on lens materials and models, information can be found on pages 38 – 42.

Prescription safety spectacles

uvex RX cf



6108200

uvex RX cf 5500

- spectacles with all-round protection
- fixed RX insert for your individual prescription
- meets the requirements for additional markings 3 (liquids, droplets) and 4 (coarse dust)
- perfect fit providing reliable protection: The side arms can be adjusted to a variety of different lengths, allowing the glasses to be adapted to suit all facial shapes
- flexible soft components adapt to the wearer's face contours

uvex RX cf 5500	
Art. no.	6108200
RX insert lens diameter	48 mm
RX insert bridge width	20 mm
Colour	blue, grey
Marking on frame	W 166 34 F CE
Lenses	PC clear
Lens marking	2C-1,2 W 1 FKN

► Please note the glazing options for uvex RX cd on pages 28/29.



6108201

uvex RX cf 5501




















- small goggles with fixed RX insert to suit your individual prescription
- meets the requirements for additional markings 3 (liquids, droplets) and 4 (coarse dust)
- highly compatible with other PPE
- low-volume frame design
- indirect ventilation

uvex RX cf 5501	
Art. no.	6108201
RX insert lens diameter	48 mm
RX insert bridge width	20 mm
Colour	black, grey
Marking on frame	W 166 34 B CE
Lenses	PC clear
Lens marking	2C-1,2 W 1 FKN

► Please note the glazing options for uvex RX cd on pages 28/29.

Prescription safety spectacles

Lens options for uvex RX sp models · Special lenses for uvex RX cf 9501

uvex RX sp 5510		Important note	Lens type	Parameter for centering of the lenses		
Description				Specific height Box measure		
	Single vision 	for uvex RX sp 5510: Minimum PD ≥ 32.0 mm Fitting height ≥ centre of lens	Single vision Single vision HD	Main line of sight		
	Comfort lenses    Nahcomfort Optima Distanzcomfort Optima Single vision Relax	for uvex RX sp 5510: Minimum PD ≥ 32.0 mm Fitting height ≥ centre of lens	Nahcomfort Optima Distanzcomfort Optima Single vision Relax	min. 17 mm Main line of sight min. 17 mm Zero line of sight min. 15 mm Zero line of sight		
	Varifocals   Varifocal Pro Work Varifocal Optima Varifocal Optima HD	for uvex RX sp 5510: Minimum PD ≥ 32.0 mm Fitting height ≥ centre of lens	Varifocal Pro Work Varifocal Optima Varifocal Optima HD	min. 20 mm Zero line of sight min. 17 mm Zero line of sight min. 16 mm Zero line of sight		
	Prescription range					
	uvex RX sp 5512 · uvex RX sp 5513					
	 	Single vision 	Minimum PD ≥ 32.0 mm Fitting height ≥ centre of lens	Single vision Single vision HD	Main line of sight	
		Comfort lenses    Nahcomfort Optima Distanzcomfort Optima Single vision Relax	Minimum PD ≥ 32.0 mm Fitting height ≥ centre of lens	Nahcomfort Optima Distanzcomfort Optima Single vision Relax	min. 17 mm Main line of sight min. 17 mm Zero line of sight min. 15 mm Zero line of sight	
		Varifocals   Varifocal Pro Work Varifocal Optima Varifocal Optima HD	Minimum PD ≥ 32.0 mm Fitting height ≥ centre of lens	Varifocal Pro Work Varifocal Optima Varifocal Optima HD	min. 20 mm Zero line of sight min. 17 mm Zero line of sight min. 16 mm Zero line of sight	
		Prescription range				
		uvex RX cf 9501				
	Description					
	Single vision 	When using PC or PC+ Minimum PD ≥ 32.0 mm When using Trivex Minimum PD ≥ 34.0 mm	Single vision Single vision HD	Main line of sight		
	Varifocals   Varifocal Pro Work Varifocal Optima Varifocal Optima HD	When using PC or PC+ Minimum PD ≥ 32.0 mm When using Trivex Minimum PD ≥ 34.0 mm	Varifocal Pro Work Varifocal Optima Varifocal Optima HD	min. 20 mm Zero line of sight min. 17 mm Zero line of sight min. 16 mm Zero line of sight		
	Prescription range					

- In order to ensure optimum vision, uvex only uses the special uvex anatomic sport glazing. The overview below provides information on the lens options for uvex RX sp frames and uvex RX goggle. Please also ensure the frame fits correctly.
- Please take into account the specifications relating to the line of sight when determining the vision point.

Material					Extras, optional				
CR 39	HI 1.6	Plastic HI 1.67	PC	Trivex	Normal AR	Super AR	UV blue protect	Tint	Variomatic brown
■	■	■	■	■	■	■	■	■	■
	incl. hard coating only available with SAR	incl. hard coating only available with SAR	incl. hard coating	incl. hard coating			only HI 1.67 or PC		only Polycarbonate or Trivex
■	■	■	■	—	■	■	only HI 1.67 or PC	—	—
■	■	■	■	—	■	■	only HI 1.67 or PC	—	—
■	■	■	■	—	■	■	only HI 1.67 or PC	—	—
■	■	■	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
■	■	■	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
■	■	■	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
+ 5.0 to - 5.0 dpt. at maximum value cyl. ±2.0 dpt.	+ 5.0 to - 5.0 dpt. at maximum value cyl. ±2.0 dpt.	+ 5.0 to - 5.0 dpt. at maximum value cyl. ±2.0 dpt.	+ 5.0 to - 5.0 dpt. at maximum value cyl. ±2.0 dpt.	+ 5.0 to - 5.0 dpt. at maximum value cyl. ±2.0 dpt.					+ 5.0 to - 5.0 dpt. at maximum value cyl. ±2.0 dpt.
■	■	■	■	■	■	■	■	■	■
	incl. hard coating	incl. hard coating only available with SAR	incl. hard coating	incl. hard coating			only HI 1.67 or PC		only Polycarbonate or Trivex
■	■	■	■	—	■	■	only HI 1.67 or PC	—	—
■	■	■	■	—	■	■	only HI 1.67 or PC	—	—
■	■	■	■	—	■	■	only HI 1.67 or PC	—	—
■	■	■	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
■	■	■	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
■	■	■	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.	+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.	+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.	+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.	+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.					+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.
Material					Extras, optional				
CR 39	HI 1.6	Plastic HI 1.67	PC/PC ⁺	Trivex	Normal AR	Super AR	UV blue protect	Tint	Variomatic brown
—	—	—	■	■	■	■	■	■	■
—	—	—	incl. hard coating	incl. hard coating			only HI 1.67 or PC		only Polycarbonate or Trivex
—	—	—	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
—	—	—	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
—	—	—	■	■	■	■	only HI 1.67 or PC	■	only Polycarbonate or Trivex
			+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.	+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.					+ 3.5 to - 3.5 dpt. at maximum value cyl. ±2.0 dpt.

uvex

Prescription safety spectacles

uvex RX cd flip-up

comfort and design
uvex RX cd flip-up

for special applications
flip-up with non-prescription special
lenses



6109218
6109235

uvex RX cd 5505 flip-up welding protection

- flip-up with welding protection lenses, non-prescription
- level of protection 5 (welding), suitable for autogenous welding
- filter technology with grey-tinted lenses provides reliable protection against UV and infrared radiation as well as ensuring perfect colour recognition
- **Note:** welding protection lenses do not provide sufficient protection against laser beams!
- level of protection 5 in accordance with EN 169 (welding), mech. strength F in accordance with EN 166

uvex RX cd 5505 flip-up welding protection		
Art. no.	6109218	6109235
Ref. no.	5505 9905 55/19	5505 9905 57/19
Lens	55 mm	57 mm
Bridge width	19 mm	19 mm
Colour	black, green	black, green
Features: flip-up		
Lens	PC grey, welding protection 5 uvex infradur plus	PC grey, welding protection 5 uvex infradur plus
Lens marking	5 W1 FTK CE	5 W1 FTK CE
Marking on frame	W 166 F CE	W 166 F CE

uvex i-3 add

Perfect vision in every situation

Optimum protective eyewear means improved, safe vision.

uvex i-3 add safety spectacles have invisible integrated dioptr correction for near vision. Strain on the eyes is effectively reduced (e.g. when reading) and the patented lens technology ensures an instant high level of compatibility for wearers. At the same time, the uvex i-3 add spectacles provide secure protection and optimal comfort.



Variable side arm inclination

The 5-position side arm inclination allows individual adjustment and optimum coverage of the eyes.



Addition

Two models are available for individualised correction of near vision. (+1.0 dpt. and +2.0 dpt.)



Flexible nose loops

The extremely soft adjustable Soffflex nose loops ensure a secure fit and can be individually adapted to sit comfortably on the nose.

uvex supravision excellence

The uvex supravision excellence coating guarantees extreme scratch resistance on the outside and permanent anti-fogging properties on the inside.


MADE IN GERMANY 

Patent no.: DE 10 2012 207 384

Perfection in every detail

The patented lens technology makes it possible to integrate two progression zones for near vision on the inside of the duospherical single lens safety spectacles. The correction strength at the bottom of the lenses is +1.0 or +2.0, depending on the model. A distinctive feature and unique selling point is that the patented manufacturing technology means the front area and consequently the base curve of the lenses are not altered.

This combines extremely good coverage and fit, all the way to the edge, together with the benefits of a progressive lens on the inside area. A further benefit is that the progressive zone is not visible and that these spectacles comply with all standards of EN norms that are relevant to safety.



optical lens designed by
optiswiss
original since 1937

Progression zones

This diagram of the lenses shows the large zone that does not feature any optical correction. The transparent, integrated optical correction starts in the region of the middle and the strength increases gradually towards the lower edge of the lenses. The correction strength of the spectacles is +1.0 or +2.0, depending on the model.

The free-form lens is manufactured in accordance with standard parameters and designed for a distance of approximately 64 mm between the eyes. These safety spectacles do not permanently replace prescription safety spectacles.

uvex i-3 add

	uvex i-3 add 1.0	uvex i-3 add 2.0
Art. no.	6108210	6108211
Frame	anthracite, lime W 166 FT CE	anthracite, lime W 166 FT CE
Lens	PC clear UV 400 2C-1.2 W 1 FTKN CE	PC clear UV 400 2C-1.2 W 1 FTKN CE
Strength	uvex supravision excellence 1.0 dpt.	uvex supravision excellence 2.0 dpt.
Order unit	PC	PC



Including soft spectacles case with microfibre cloth

Prescription safety spectacles


Certification and marking

Certification

Individually manufactured uvex prescription safety spectacles are tested and certified by independent testing institutes at regular intervals according to the requirements of EN 166.



Marking of lenses in accordance with EN 166



Note: Due to the mandatory marking, it is not possible to purchase frames without lenses. Please do not modify the completed spectacles in a way that reduces their protective function.

- S** **Increased robustness:** Ball bearing drop test, Dropping a ball bearing (44 g) against the lens from a height of 1.30 m
- F** **Impact-resistant, low energy:** Firing a ball bearing (0.88 g) against the lens, impact speed 45 m/s (±162 km/h)
- B** **Impact-resistant, medium energy:** Firing a ball bearing (0.88 g) against the lens, impact speed 120 m/s (±432 km/h)
- T** Optional requirements in accordance with EN 166 (extract): **Tested in extreme temperatures (-5°C, +55°C)**, this marking is always in combination with mechanical strength (for example, FT)

Prescription safety spectacles

Certification and marking


Marking

- frame and lenses are permanently marked
- if the markings on the lens and frame are different, the lower mechanical strength applies to the entire eye protection device
- according to the PPE regulation, uvex prescription safety spectacles must be marked with the factory symbol and production date: ☐ MM/YYYY



Marking in accordance with EN 166 on the lens and inside of the frame

Marking of the frame in accordance with EN 166



Prescription safety spectacles

Focus types

Single vision lenses

Single vision

- defective vision caused by long-sightedness or short-sightedness is corrected

Single vision HD – the ultimate in customisation!

- free-form single-vision lens
- individual parameters such as cornea vertex distance, frame wrap angle and inclination are taken into account for production purposes.
- calculation of dioptres to an accuracy of one hundredth



Comfort lenses

- ideal for use at workstations with monitors
- comfort lenses relieve the eye when looking at objects close up and at intermediate distances thanks to their seamless correction areas
- comfort lenses are a good alternative if the prescription safety eyewear is only needed at workstations and distance vision (> 5 m distance) is not necessary.



Nahcomfort Standard, Nahcomfort Optima

- perfect solution for working distances between 30 cm and approx. 2 m
- the medium range of the lens surface is determined by the degression chosen and is designed for a distance of approx. 60 cm to 80 cm
- three versions are available, depending on the required reading addition (optional based on the age of the wearer)
- all that is needed to place an order are details of the close-range values and the required design (type A, B, C)
- when ordering the Nahcomfort Optima option, the inner surface of the raw lenses is calculated and manufactured, taking into account the correction, the glass curve and the distance between the eyes

Type A	Type B	Type C
Degression** 0.75 dpt	Degression** 1.25 dpt	Degression** 1.75 dpt
Addition < 1.5 dpt.	Addition 1.5 to 2.25 dpt.	Addition > 2.25 dpt.
< 50 years	50 to 55 years	> 55 years

** Degression: Correction reduced, based on the close-range value!

Note:

Ideal for use in VDU spectacles. About 60% of degression is active at the centring cross, so the recommended adjustment applies on the main line of sight.

Distanzcomfort Optima

- perfect solution for working distances between 30 cm and around 1 m, 2 m or 4 m
- by specifying the viewing distance that is required at the workstation, the correction areas will be calculated individually
- all that is needed to place an order are details of the distance and close-range values (addition), the maximum viewing distance (one, two or four meters) as well as the centering parameters (pupillary distance and specific height)
- recommended adjustment: zero line of sight, distance values and addition

Single Vision Relax

- this type of lens is targeted at people over the age of 30
- an invisibly integrated change to the correction value of +0.5 dpt. in the lower area of the lens eases the strain on the eye when looking at near distances (accommodation support)
- the distance correction remains unchanged
- all that is needed to place an order the details of distance values and centring parameters (pupillary distance and specific height)
- we recommend Single Vision Relax lenses for professionals who use mobile devices (notebook, tablet, smartphone etc.) for their daily work

Prescription safety spectacles

Focus types



Bifocal lenses

Bifocal

- visibly ground segment for near vision ('reading field')
- instant wearer acceptance as visible edge helps eyes to adjust
- intermediate ranges are not corrected



Varifocal lenses

- gradual transition from distance to near vision, known as the progression zone
- the invisible progression zone also corrects intermediate distances
- clear vision at all viewing distances
- may require an initial adjustment phase



Varifocal Optima HD – the ultimate in customisation!

- free-form varifocal lens taking into account individual parameters such as cornea vertex distance, frame wrap angle and inclination
- calculation of dioptres to an accuracy of one hundredth

uvex RX lens consulting

Optimal selection of products – conveniently online

What are the advantages of the different lens types and coatings for innovative uvex prescription safety spectacles? Find the optimum product to meet requirements quickly and easily using the practical uvex RX app.



www.uvex-safety.com/en/uvex-rx-lens-consulting/

Prescription safety spectacles

Lens material



Polycarbonate

- mechanical strength 'F' (45 m/sec)
- organic material with very high breaking strength
- only partially chemical-resistant
- PC⁺ – polycarbonate with increased centre thickness and mechanical strength 'B' (120 m/sec), especially for the uvex RX goggle
- PC and PC⁺: Identification code: 2C-1.2 as per EN 170

Trivex™

- mechanical strength 'F' (45 m/sec)
- best all-round lens material
- excellent resistance to cleaning agents, oils and cosmetics and good scratch resistance
- lightweight, suitable for even higher prescription values

CR39, modified (plastic)

- mechanical strength 'S' (ball drop test)
- lightweight organic material suitable for chemicals and painting
- good scratch resistance due to hard coating (optional)

HI (high index)

Organic lenses with high refractive index – 1.6 or 1.67

- mechanical strength 'S' (ball drop test)
- organic material suitable for chemicals and painting
- the lens is thinner and more aesthetically pleasing

HI 1.6 recommended for a prescription > +/-4.0 dpt.
HI 1.67 recommended for a prescription > +/-6.0 dpt.

Hard glass, modified

(crown glass, silicate, mineral glass, glass)


- mechanical strength 'S' (ball drop test)
- highly scratch-resistant surface suitable for working with chemicals and paints
- heavy, not recommended for prescription values greater than +/-4.0 dpt.
- spark penetration when welding or grinding

UV blue protect

A special absorber has been added to the lens material that completely filters out UV rays and reduces the blue light content.

- the lenses absorb UV radiation up to 400 nm at 100%, filter short-wave blue light until 410 nm almost completely and reduce the range from 410 nm to 420 nm around 86%.
- uvex UV blue protect lenses enhance contrast and effectively prevent signs of fatigue and age-related macular degeneration (AMD)
- UV blue protect is optionally available for polycarbonate (PC) lenses and HI 1.67

- the mechanical strength of the lenses is guaranteed – clear lenses with UV blue protect are marked 2C-1.2 according to EN 170



Prescription safety spectacles

Finishes


Anti-reflective coating

Anti-reflective coating is applied to the inside and outside of lenses by means of vapour deposition. It significantly reduces reflections on the surfaces. It offers a cosmetic advantage and increases light transmission.

Two qualities are available:

- normal anti-reflective coating
- super anti-reflective coating

Normal anti-reflective coating	Super anti-reflective coating
Good reflection reduction	Maximum reflection reduction
Metal oxide is applied once to each surface	Metal oxide is applied several times to each surface
Residual reflection \approx 4%	Residual reflection $<$ 2%



Scratch-resistant coating

To guarantee an ideal surface hardness, all our plastic lenses are given a hard coating (optional for CR 39).



Tint


Tinted lenses provide effective protection against glare in areas with high light intensity (for example, sunlight)

Constant tinting

- available in brown and grey
- tinting levels: 15%, 25%, 65%, 75%

Variable tinting – Variomatic™

- lenses tint automatically depending on the UV radiation and temperature
- tinting of between approx. 8% and 80%, in brown
- available as prescription safety spectacles in polycarbonate and Trivex™



VDU spectacles

Individual eye protection at the screen

**MADE FOR
YOUR EYES**
MADE IN **UVEX**



uvex VDU spectacles are specially designed for working at a screen, enabling problem-free vision at a computer workstation.

The special feature of VDU spectacles is the distance for which they have been optimised. Normally, the lens is designed for a viewing distance of approximately 30 cm (reading distance) to correct presbyopia. A screen is usually about 50 cm – 80 cm away from the human eye.

To be able to focus continuously at different distances, spectacle wearers are forced to adopt an unnatural head position and body posture. This can lead to a variety of posture-related symptoms, such as overexertion of the

shoulder and neck muscles, fatigue symptoms or headaches. For most people who wear reading glasses or varifocals in their everyday lives, VDU spectacles are recommended if the main activity in their job requires viewing a computer screen and safety spectacles are not mandatory in the workplace.

uvex offers different lens materials, focus types and frames for VDU spectacles. The 'Made in uvex' quality system guarantees the best design from an optical and processing technology perspective. All materials used are free from harmful substances and are regularly inspected.

The collection

uvex offers different frames for VDU spectacles. Numerous models are available as metal, plastic or titanium frames.

Metal frames



Plastic frames



Titanium frames



VDU spectacles

Individual eye protection at the screen

uvex as a partner for individual VDU spectacles

The position of the screen, keyboard and documents in offices is a special visual requirement. uvex offers individual solutions in the area of VDU spectacles. Decades of experience and innovative technologies form the basis for the uvex products, which are manufactured according to the

highest production standards. In addition to symptom-free vision at work, uvex also guarantees maximum comfort and quality. Employees will be happy to wear those VDU spectacles which fit perfectly and provide reliable support.

Our service – your benefits

uvex offers maximum service with maximum flexibility. Our specialists are happy to advise you with regard to professional and flexible solutions, tailored to the individual requirements of your company.

Our wide uvex collection enables us to find VDU spectacles for each of your employees.



uvex experts:

- on-site service from qualified opticians and master opticians
- qualified advisers in uvex customer service
- comprehensive uvex optical service partner network in Germany, Austria and Switzerland, as well as in other European countries



uvex flexibility:

- product consultation and adaptations on request.
- appointments are also possible during the early, late or night shift
- uvex online appointment tool optimises planning




uvex expertise:

- decades of experience in optics and continuous development of products
- training courses/practical seminars for your employees (e.g. company doctors, occupational safety specialists)
- 'Made in uvex' quality: First-class products with an in-house value creation chain and a focus on production facilities in Germany/Europe



digital service tools:

- uvex RX lens consulting for the optimal product selection for your requirements
- uvex centRX, the web-based centring tool for determining the necessary centring parameters for your custom prescription VDU spectacles order



www.uvex-safety.com/en/individual-ppe/digital-servicetools/

The easy steps to your VDU spectacles

1 Scheduled appointment and consultation

Make an appointment by phone or email and get advice from uvex experts on the topic of VDU spectacles.

+49 911 97361400

customerservice.sbu-oh@uvex.de

2 Workplace analysis and product search

Our uvex specialists will be happy to present our uvex collection to you in person at your company, and will carry out a workplace analysis with you in order to find the optimal products for you and your employees.

3 Finished VDU spectacles

After consulting and selecting your personal product, either on-site or at one of the uvex optical service partners, the VDU spectacles will be ready for you in a timely manner.

Please contact us for further, non-binding information.

VDU spectacles

Focus types

Posture-related symptoms? The solution – uvex Nahcomfort lenses

Avoid posture-related symptoms with VDU spectacles that are individually adjusted to the wearer. Nahcomfort lenses are specially designed to suit computer-based workplaces and provide unrestricted vision at VDU workstations. The advantages are seamless, sharp vision from 30 cm to approx. 2 m. A clear view of keyboard, screen and documents with an ideal head position. This results in a marked reduction in posture-related symptoms, because the head and neck remain in a natural position.



Nahcomfort



- the wearer's usual reading prescription is found in the lower part of the lens.
- the prescription value gradually becomes weaker further up the lens (degression, in the upper part of the lens, vision is clear at a maximum distance of approx. 2 m). The transitions between the different zones are smooth, similar to varifocal lenses.
- all that is needed to place an order are details of the close-range values and the required design (type A, B, C).
- it is necessary to measure the specific height on the basis of the main line of sight. A minimum fitting height of 17 mm in the frame must be observed.

Type A	Type B	Type C
Degression** 0.75 dpt	Degression** 1.25 dpt	Degression** 1.75 dpt
Addition < 1.5 dpt.	Addition 1.75 to 2.25 dpt.	Addition > 2.25 dpt.
< 50 years	50 to 55 years	> 55 years

VDU spectacles

Finishes

uvex UV blue

- surface finish consisting of different layers. It includes a layer that filters short-wave visible light in the blue-violet range with increased effect.
- effective protection against the symptoms of fatigue and headaches associated predominantly with long periods of working at a monitor and/or with digital media.
- the uvex UV blue layer system also includes a super anti-reflection coating, a scratch-resistant coating and an easy-care layer.



Tint


Tinted lenses provide effective protection against glare in areas with high light intensity (for example, sunlight)

Constant tinting

- available in brown and grey
- tinting levels: 15%, 25%, 65%, 75%

Variable tinting – Variomatic™


- lenses tint automatically, depending on the UV radiation and temperature
- tinting of between approx. 8% and 80% in brown or grey
- available with lens material CR 39



Super anti-reflection incl. easy-care layer

Anti-reflective coating is applied to the inside and outside of lenses by means of vapour deposition. It significantly reduces reflections on the surfaces. It offers a cosmetic advantage and increases light transmission. The easy-care layer makes the glasses easier to clean.

- Maximum reflection reduction
- Metal oxide is applied several times to each surface
- Residual reflection < 2%



VDU spectacles

Metal frames

VDU spectacles

Metal frames

ideal for VDU work,
for use in workplaces where it is not
mandatory to wear safety spectacles
designs from classic to modern



6110062



6110063



6110064



6110065



6110066

Art. no.	uvex RX 3119 6110062	uvex RX 3119 6110063	uvex RX 3120 6110064	uvex RX 3120 6110065	uvex RX 3121 6110066
Ref. no.	3119 6300 50/19	3119 1200 50/19	3120 1800 55/17	3120 3026 55/17	3121 1300 57/19
Lens diameter	50 mm	50 mm	55 mm	55 mm	57 mm
Bridge width	19 mm	19 mm	17 mm	17 mm	19 mm
Colour	rose gold, shiny	black, matt	silver, shiny	dark blue, matt	anthracite, shiny
Extras	Spring hinge	Spring hinge	Spring hinge	Spring hinge	Spring hinge

VDU spectacles
Metal frames



6110050



6110067



6110056



6110068



6110069

	uvex RX 3112	uvex RX 3118	uvex RX 3122	uvex RX 3123	uvex RX 3124
Art. no.	6110050	6110056	6110067	6110068	6110069
Ref. no.	3112 1233 54/17	3118 7190 55/17	3122 7014 59/18	3123 1436 52/21	3124 1800 53/16
Lens diameter	54 mm	55 mm	59 mm	52 mm	53 mm
Bridge width	17 mm	17 mm	18 mm	21 mm	16 mm
Colour	black, blue	petrol, vintage	dark green, gun	gun, blue	silver
Extras	Spring hinge	Spring hinge	Spring hinge	Spring hinge	Spring hinge

VDU spectacles

Plastic frames



VDU spectacles

Plastic frames

ideal for screen work,
in workplaces where it is not man-
datory to wear safety spectacles
designs from classic to modern



6110073



6110075



6110074



6110076



6110077

	uvex RX 3516	uvex RX 3517	uvex RX 3518	uvex RX 3519	uvex RX 3520
Art. no.	6110073	6110074	6110075	6110076	6110077
Ref. no.	3516 1525 52/16	3517 5400 55/20	3518 1525 49/21	3519 1000 51/21	3520 5500 52/18
Lens diameter	52 mm	55 mm	49 mm	51 mm	52 mm
Bridge width	16 mm	20 mm	21 mm	21 mm	18 mm
Colour	grey, translucent	havanna	grey, translucent	black	brown
Extras	Spring hinge				Spring hinge

VDU spectacles
Plastic frames



6110078



6110081



6110079



6110082



6110080



6110083

	uvex RX 3521	uvex RX 3522	uvex RX 3523	uvex RX 3524	uvex RX 3525	uvex RX 3526
Art. no.	6110078	6110079	6110080	6110081	6110082	6110083
Ref. no.	3521 4364 54/15	3522 5717 53/17	3523 1370 54/16	3524 1510 56/16	3525 1029 59/17	3526 2415 54/15
Lens diameter	54 mm	53 mm	54 mm	56 mm	59 mm	54 mm
Bridge width	15 mm	17 mm	16 mm	16 mm	17 mm	15 mm
Colour	violet, rosé	beige, light grey	anthracite, dark green	translucent-grey, black	black, transparent	dark grey
Extras	Spring hinge	Spring hinge		Spring hinge	Spring hinge	Spring hinge

uvex

VDU spectacles

Titanium frames

Titanium uvex RX ti

ideal for screen work,
in workplaces where it is not man-
datory to wear safety spectacles
lightweight
allergy-neutral



6110071



6110070



6110072

Art. no.	uvex RX ti 3902 6110070	uvex RX ti 3903 6110071	uvex RX ti 3904 6110072
Ref. no.	3902 1830 55/18	3903 3035 49/21	3904 1900 53/17
Lens diameter	55 mm	49 mm	53 mm
Bridge width	18 mm	21 mm	17 mm
Colour	silver, dark blue	dark blue, light blue	silver, matt
Extras	Spring hinge		



uvex academy



You can find more information at uvex-academy.com

Prescription spectacles and workplace safety

The common key features of prescription safety spectacles are that they compensate the wearer's defective vision and protect the eyes from mechanical and optical influences. This seminar will enable participants to act as a competent representative within the company for prescription safety spectacles right through to fitting.

- Ability to determine the necessary parameters for fitting prescription spectacles
- Practical demonstration of selection, consultation, and fitting of prescription safety glasses
- Instruction regarding the best care and handling of prescription safety spectacles

Target group

Those responsible for the work-related health and safety of employees within a company and/or those who are to fit prescription safety spectacles, such as safety officers, company doctors and their support staff.



- Information regarding legal regulations, test specifications and standards
- Sharing knowledge about prescription safety spectacles
- Explanation of the different types of lens and frame materials available, their specific features and properties
- Explanation of the various focus types and their best use
- Assessment of the risks in the respective workplace and selection of the most appropriate prescription safety spectacles

For further information and to register visit uvex-academy.com, phone +49 911 9736-1710 or e-mail academy@uvex.de



uvex academy

uvex



09.24/PDF · Rights of technical changes reserved.
© 2024 – UVEX ARBEITSSCHUTZ GmbH

UVEX ARBEITSSCHUTZ GMBH
SBU Occupational Health
Wuerzburger Str. 152
90766 Fuerth
GERMANY

T: +49 911 9736-1400
F: +49 911 9736-1679
E: customerservice.sbu-oh@uvex.de
I: uvex-safety.com

protecting people